



**evolution**  
POWER TOOLS

**RAGE 2**  
Multi Purpose S.A.W.

Service Parts List

REV. 1.00

Item	Description	Part No	Qty	List €	Item	Description	Part No	Qty	List €	Item	Description	Part No	Qty	List €
M1	Head Lock down unit	R2SM1	1	9.50	61	Adjusting screw M8x50	R2S61	1	2.45	140	Swarf tray	R2S140	1	22.46
M2	Back vice	R2SM2	1	35.36	62	Washer	R2S62	2	0.44	141	Swarf tray cover	R2S141	1	13.12
M3	Vice screw unit	R2SM3	1	11.72	63	Spring washer	R2S63	2	0.75	142	Screw M4x10	R2S142	10	0.61
1	Screw M5x16	R2S1	2	0.61	64	Inner Hex Bolt M6x20	R2S64	2	1.22	143	Rubber foot	R2S143	4	4.67
2	Dust filter	R2S2	1	2.65	65	Connecting plate	R2S65	1	2.45	144	Cap screw M8x35	R2S144	4	3.06
3	Bearing support plate	R2S3	1	0.67	71	Allen wrench 8mm	R2S71	1	1.25	145	Flat washer	R2S145	2	0.50
4	Wave washer	R2S4	1	0.58	72	Screw M5x15	R2S72	2	0.61	146	Spring washer	R2S146	2	0.75
5	Screw M5x10	R2S5	2	0.61	73	Wrench holder	R2S73	1	0.44	147	Cap screw M8x30	R2S147	2	2.45
6	Washer	R2S6	2	0.29	74	Base	R2S74	1	102.83					
7A	Label set 230v	R2S7A	1	1.64	75	Washer	R2S75	4	0.44					
8	Cap screw M5x15	R2S8	2	1.25	76	Spring washer	R2S76	4	0.75					
9	Depth stop	R2S9	1	1.20	77	Cap screw M10x30	R2S77	4	1.22					
10	Motor housing	R2S10	1	60.79	78	Nut	R2S78	1	0.44					
12	Wave washer	R2S12	1	0.60	79	Washer	R2S79	1	0.44					
13	Screw M5x10	R2S13	1	0.61	80	Spring washer	R2S80	1	0.75					
14	Left handle	R2S14	1	9.18	81	Cap screw M6x28	R2S81	1	1.22					
15	Tapping screw ST4.2x25	R2S15	6	0.56	82	Washer	R2S82	1	0.44					
16	Screw M5x45	R2S16	1	0.92	83	Spring washer	R2S83	1	0.75					
17	Screw M5x50	R2S17	1	0.92	84	Cap screw M5x20	R2S84	1	1.22					
18	Screw M5x30	R2S18	1	0.92	88	Washer	R2S88	1	0.44					
19	Tapping screw ST4.2x19	R2S19	3	0.56	89	Spring washer 10	R2S89	1	0.75					
20	Tapping screw ST4.2x15	R2S20	2	0.56	90	Cap screw M10x25	R2S90	1	1.22					
21	Cable clamp	R2S21	1	1.11	96	V-vice	R2S96	1	10.14					
22	Cable sheath	R2S22	1	2.67	97	Cast iron plate	R2S97	1	28.69					
23B	Cable & Plug 230v EU	R2S23B	1	19.52	98	Lock Ring	R2S98	1	1.00					
24	Right handle	R2S24	1	9.18	99	Moving vice jaw	R2S99	1	16.01					
25	Nut M5	R2S25	3	0.62	100	Split Pin 3x26	R2S100	1	0.44					
26	On/Off Switch	R2S26	1	27.32	101	Washer	R2S101	1	0.44					
27	Rubber cover	R2S27	1	0.75	102	Connecting rod	R2S102	1	5.60					
28	Carbon brush holder	R2S28	2	7.71	103	Vice screw support	R2S103	1	13.08					
29	Carbon brush (pair)	R2S29	1	16.99	104	Handle set	R2S104	1	16.81					
30	Carbon brush holder cap	R2S30	2	1.47	106	Plastic guard	R2S106	1	7.47					
31A	Armature 230v	R2S31A	1	78.17	107	Cap screw M4x12	R2S107	2	1.22					
32	Spring washer	R2S32	1	0.60	108	Blade guard (1)	R2S108	1	60.45					
33	Screw M5x80	R2S33	1	1.22	109	Screw M5x90	R2S109	4	1.22					
34	Air baffle	R2S34	1	1.73	110	Rubber ring	R2S110	2	0.92					
35	Bearing (6200)	R2S35	1	9.79	111	Screw M5x12	R2S111	1	0.61					
36A	Field Coil 230v	R2S36A	1	57.31	112	Screw M4x10	R2S112	1	0.61					
37	Bearing (6202)	R2S37	1	11.92	113	Spring	R2S113	1	1.83					
38	Gearbox cover	R2S38	1	20.32	114	Screw M4x10	R2S114	1	0.61					
39	Key 5x10	R2S39	1	0.60	115	Blade guard (2)	R2S115	1	56.31					
40	Spring	R2S40	1	0.90	116	Circlip 42	R2S116	1	1.39					
41	Circlip	R2S41	1	0.60	117	Inner flange	R2S117	1	17.35					
42	Spindle lock	R2S42	1	5.20	118	Screw (2)	R2S118	1	0.61					
43	Bearing (6000)	R2S43	1	6.05	119	Plastic wheel	R2S119	1	2.67					
44	Gear	R2S44	1	31.32	120	Connecting rod (1)	R2S120	1	3.74					
45	Flat key 5x12	R2S45	1	0.50	121	Screw (4)	R2S121	1	1.95					
46	Shaft (1)	R2S46	1	20.82	122	Nut M5	R2S122	1	0.50					
47	Bearing (6200)	R2S47	1	9.79	123	Connecting rod (2)	R2S123	1	1.47					
48	Bearing (6001)	R2S48	1	6.94	124	Screw (1)	R2S124	1	0.61					
49	Gear	R2S49	1	31.32	125	Screw (3)	R2S125	1	0.61					
50	Flat key 6x12	R2S50	1	0.67	126	Blade guard (3)	R2S126	1	22.28					
51	Shaft (2)	R2S51	1	13.61	127	Spring washer	R2S127	4	0.92					
52	Bearing (6204)	R2S52	1	12.45	128	Screw M4x10	R2S128	4	0.61					
53	Gearbox	R2S53	1	20.32	130	Blade guard cover	R2S130	1	12.68					
54	Circlip	R2S54	1	5.12	131	Washer	R2S131	1	0.50					
55	Screw M4x12	R2S55	3	1.22	132	Screw	R2S132	1	0.61					
56	Spring washer	R2S56	2	1.33	134	Screw Knob	R2S134	1	3.06					
57	Pivot pin	R2S57	1	3.30	136	Outer flange	R2S136	1	17.35					
58	Torsion spring	R2S58	1	4.18	137	Washer	R2S137	1	0.50					
59	Aluminum support	R2S59	1	57.13	138	Spring Washer	R2S138	1	0.75					
60	Nut M8	R2S60	1	0.44	139	Cap screw M10x25	R2S139	1	1.22					

Evolution Power Tools Ltd  
Evolution House, New Street, Holbrook Industrial Estate, Sheffield, S20 3GH, UK  
Tel: +44 (0) 870 609 2297 Fax: +44 (0) 114 247 3339 www.evolutionpowertools.com

**evolution** POWER TOOLS **RAGE 2**  
Multi Purpose S.A.W.

**Service Parts List** REV. 1.00