



**evolution** POWER TOOLS **FURY 3**  
Dual Rail Slide Mitre S.A.W.

**Service Parts List** REV. 1.04

Item	Description	Part No	Qty	Item	Description	Part No	Qty	Item	Description	Part No	Qty
M1	Back clamp unit	F3SM1	1	64	Bearing separator sleeve	F3S64	1	148	Brush holder cap	F3S148	2
M2	Bevel lever kit	F3SM2	1	65	Sliding bar support pad	F3S65	4	149	Tapping screw ST4x12	F3S149	2
M3	Extension support stop	F3SM3	1	66	Angle scale	F3S66	1	150	Rear cover	F3S150	1
M4	Laser unit kit	F3SM4	1	67	Hexagon nut M8	F3S67	4	151C	Power cord 115v US	F3S151C	1
M5	Guard mech kit	F3SM5	1	68	Grub screw M8x16	F3S68	4	152	Cable sheath	F3S152	1
M7	Gearbox unit	F3SM7	1	69	Bevel bracket	F3S69	1	153	Head pivot stop	F3S153	1
M8	Channel guide kit	F3SM8	1	70	Spring	F3S70	1	165	Flat washer 5mm	F3S165	4
M9	Front clamp unit	F3SM9	1	71	Slide locking knob	F3S71	1	170	Laser protector	F3S170	2
1	Extension support	F3S1	2	72	Back support	F3S72	1	171	Blade spanner	F3S171	1
2	Rubber foot	F3S2	4	73	Cable clamp	F3S73	1	172	Exhaust port tube	F3S172	1
3	Flat washer 4mm dia	F3S3	8	74	Flat washer 12mm	F3S74	2	173	Exhaust port plug	F3S173	1
4	Cross head screw M4x10	F3S4	22	75	Wave washer 12mm	F3S75	1	174	Dust bag	F3S174	1
5	Flat washer 10mm	F3S5	2	76	Nylock nut M12	F3S76	1				
6	Wave washer 10mm	F3S6	1	82	Hex bolt M8x20 (l/hand thread)	F3S82	1				
7	Nylock nut M10	F3S7	1	83	Washer 8mm	F3S83	1				
8	Cross head screw M5x14	F3S8	2	84	Outer flange	F3S84	1				
9	Base	F3S9	1	86	Inner flange	F3S86	1				
10	Tapping screw ST4x16	F3S10	3	87	Ext circlip 38mm	F3S87	1				
11	Guard release clip	F3S11	1	88	Movable blade guard	F3S88	1				
12	Table positioning handle	F3S12	1	89	Speed sensor	F3S89	1				
13	Spring	F3S13	1	90	Magnet	F3S90	1				
14	Table locking knob	F3S14	1	91	Cross head screw M3x5	F3S91	1				
15	Table locking pad	F3S15	1	92	Guard return spring	F3S92	1				
16	Cross head screw M5x10	F3S16	4	102	Left handle	F3S102	1				
17	Support block	F3S17	1	104	Capacitor (115v Unit)	F3S104	1				
18	Nylock nut M6	F3S18	1	105	On/Off switch	F3S105	1				
19	Table locking clamp	F3S19	1	106	Spring for lock switch	F3S106	1				
20	Screw	F3S20	1	107	Lock switch knob	F3S107	1				
21	Table	F3S21	1	108	Middle rod lock switch	F3S108	1				
22	Table angle indicator	F3S22	1	109	Lower rod lock switch	F3S109	1				
23	Hexagon head bolt M10x45	F3S23	1	110	Middle rod spring	F3S110	1				
26	Wing screw	F3S26	2	111	Cross head screw M4x10	F3S111	1				
27	Self tapping screw ST4x45	F3S27	2	112	Right handle	F3S112	1				
28	Cable clamp	F3S28	1	113	Self tapping screw ST4x20	F3S113	1				
29	Connection block	F3S29	10	114	Guard release screw	F3S114	1				
30	Terminal box base	F3S30	1	121	Spindle lock	F3S121	1				
31	Laser transformer 115v	F3S31	1	122	Split Pin 3x20	F3S122	1				
32	Terminal box lid	F3S32	1	123	Spring	F3S123	1				
33	Laser switch	F3S33	1	124	Cover stop block	F3S124	1				
38	Back fence	F3S38	1	125	Frame safety cover	F3S125	1				
39	Flat washer 6mm dia	F3S39	4	126	Gearbox housing	F3S126	1				
40	Cap screw M6x22	F3S40	6	127	Blade housing	F3S127	1				
41	Cap screw M8x25	F3S41	3	128	Limiting block	F3S128	1				
42	Connecting bolt	F3S42	1	129	Cap screw M4x6	F3S129	1				
43	Hexagon nut M6	F3S43	2	130	Wing nut	F3S130	1				
44	Bevel bracket seat	F3S44	1	131	Limiting stop screw	F3S131	1				
45	Bevel angle indicator	F3S45	1	132	Seal plate	F3S132	1				
49	Pin 6x45	F3S49	4	133	Seal ring	F3S133	1				
50	Head pivot axle	F3S50	1	134	Ball bearing 6000	F3S134	1				
51	Torsion spring	F3S51	1	135	PCB 115v	F3S135	1				
52	Head pivot block	F3S52	1	136	PCB cover	F3S136	1				
53	Head lockdown pin	F3S53	1	137	Armature 115v	F3S137	1				
54	O seal ring	F3S54	1	138	Ball bearing 608	F3S138	1				
55	Rubber stop	F3S55	2	139	Air baffle	F3S139	1				
56	Lockdown pin knob	F3S56	1	140	Self tapping screw ST4x68	F3S140	2				
57	Main sliding shaft	F3S57	1	141	Spring washer 5mm dia	F3S141	6				
58	Secondary sliding shaft	F3S58	1	142	Field coil 115v	F3S142	1				
59	Spring washer 4mm	F3S59	4	143	Motor housing	F3S143	1				
60	Bevel bracket cover	F3S60	2	144	Label set 115v	F3S144	1				
61	Main sliding shaft seal ring	F3S61	4	145	Cross head screw M5x30	F3S145	4				
62	Anti-friction ring	F3S62	1	146	Brush holder	F3S146	2				
63	Linear ball bearing	F3S63	2	147	Carbon brush (pair)	F3S147	1				

Evolution Power Tools LLC  
 5567 Carey Avenue, Davenport, Iowa, 52807, USA  
 Tel: 1 866 386 8665 Fax: 1 563 386 8010 www.evolutionpowertools.com



## FURY 3

Dual Rail Slide Mitre S.A.W.

# Service Parts List

REV.  
1.04